



Andoer HDV 107 Lens Replacement

Replace lens

Written By: Isaac Saron



INTRODUCTION

This guide is to replace the lens component in case it was not working properly due to scratches.

TOOLS:

- [Phillips #000 Screwdriver](#) (1)
-

Step 1 — Lens



- Remove the top screw to the right of the screen.

Step 2



- Now remove the lens by grabbing it and pulling it away from the camera.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-02 01:29:55 AM.